



ADDITIONAL NOTES

ALL OF THE EXPANSION VESSEL PIPEWORK MUST BE COPPER.

THE ADDITIONAL 1.5 - 2.5bar PRV MUST BE FITTED AS THE STANDARD CONNECTION KIT 3bar PRV IS RATED ABOVE THE BOILERS MAXIMUM RUNNING PRESSURE.

DRAINAGE POINTS MUST BE FITTED SO THAT THE VERY HOT DISCHARGE WATER DOES NOT IMPOSE A DANGER TO THE PEOPLE / ANIMALS.

JASPI UK www.jaspi.co.uk			
Multifuel boilers Expansion vessel connection			
DRAWN	VERSION	DATE	DRAWING REF.
SS		11.06.2011	Generic